

Panels

Installation Instructions



***For specific advice on installation contact Boyd Visuals.
This advice is designed to assist experienced installers in standard applications.***

Before Installation

Slight colour variations can be present between batches. Please check that your product order does not show any colour variation before installation. Ensure that the Acoustic Panels are not bent during storage or prior to installation as this can cause creases. Also ensure that edges are protected from damage. A clean environment and clean hands are essential to ensure panels are not marked.

Adhesive

We recommend a contact adhesive, sprayed on to the panel and the substrate.

Cutting

Cutting of Boyd Visuals Acoustic Panels can be done with a slide cutter, craft knife or circular saw.

Installation

Ensure hands are clean or gloves are worn, particularly when installing light coloured panels. Boyd Visuals Acoustic Panels should be applied to flat wall substrates. Install each panel separately. Apply adhesive (details above) to both the panel and substrate ensuring all areas are masked off to prevent over spray. Once the adhesive is tacky fit the Panel to the wall starting with any joins first. Smooth the entire surface from the centre outwards to ensure a good adhesive bond. Press firmly on to the substrate.

Substrate

Acoustic Panels can be applied to a wide range of surfaces. A level 3 finish is recommended. Surfaces should be clean, free of dust and dry. Acoustic Panels can be applied over small gaps in substrate but it is recommended that any gaps are sealed with tape before installation. Gloss finishes should be sanded prior to application.